


SENCOR®

SFP 5960



USER'S MANUAL

NÁVOD K OBSLUZE

NÁVOD NA OBSLUHU

FELHASZNÁLÓI KÉZIKÖNYV

INSTRUKCJA OBSŁUGI

SQUARE MP4 Player

SQUARE MP4 PŘEHRÁVAČ

MP4 PREHRÁVAČ SQUARE Q5

SQUARE Q5 - MP4 LEJÁTSZÓ


ODTWARZACZ MP4 SQUARE Q5

EN CZ SK HU PL

1. Key features

- 1.5 inch TFT screen
- Support MP3, WMA, FLAC, APE formats audio
- Support MPEG-4 (AVI) format video
- Support FM Radio
- Lyric display synchronously
- Multi EQ modes and repeat modes
- Support JPG format picture view
- Built-in microphone for long time recording
- Support txt E-book reading
- Multi-Languages OSD menu

2. Player Layout




1. earphone port
2. volume +
3. volume -
4. power on/off
5. microphone
6. usb port
7. last/fast backward
8. next/fast forward
9. menu
10. play/pause
11. neck strap
12. display

3. Operation instruction

- **Power On/Off**
In the status of power off, push power button to on, then long press ►|| to turn on the player
In the status of power on, long press ►|| to turn off, then push power button to off.
- **Lock/Hold:**
Press MENU and ►|| at the same time to lock the player, press them again to unlock the player.
- **Basic Operation**
In main menu interface, press ◀/▶ or +/- to select option, press ►|| to enter. Long press MENU to get back to main menu interface.

3.1 Music



In Main interface, short press ◀/▶ or +/- to select **Music** menu, then short press ►|| to enter music play interface.

Play/Pause: short press ►|| to play or pause the music playing.

Last/next: short press ◀ or ▶ to get to last music or next music.

Fast backward/Fast forward: long press ◀ or ▶ to fast backwards or forwards the music.

Volume: press + or - to adjust volume up or down.

A-B repeat: long press volume + button to set repeat start point A, long press again to set repeat end point B. Then player will repeat the segment. The third time long press will cancel A-B repeat and resume normal playback.

Lyric show: To show the lyric, the lyric file (eg. Abcde.lrc) should be in same name as music file (eg. Abcde.mp3) and both files should be in the same folder.


Music file list: in playback interface, press MENU button to get to folder/file list. Press ◀/▶ to select music file, press ►|| button to play it.

Set EQ: please get to **Settings > Music** to set EQ. (reference to 3.8.1)

Set Play/Repeat mode: please get to **Settings > Music** to set Play mode. (reference to 3.8.1)

Remark: the player support audio formats of .mp3, .wma, .wav, .flac, .ape.

3.2 Video



In Main interface, short press ◀/▶ or +/- to select **Video** menu, then short press ►|| to enter video file list. Press ◀/▶ to select video file, press ►|| button to enter video playback interface.

Play/Pause: short press ►|| to play or pause the video playing.

Last/next: short press ◀ or ▶ to get last or next video.

Fast backward/Fast forward: long press ◀ or ▶ to fast backwards or forwards the video.

Volume: press + or - to adjust volume up or down.

Video file list: in playback interface, press MENU button to get to folder/file list. Press ◀/▶ to select video file, press ►|| button to play it.

Remark: the player support video formats of .avi. Resolution should be 128x128. Please use video converting tool in gift CD to convert the video to which this player support (reference to point 5).

3.3 FM Radio



In Main interface, short press ◀/▶ or +/- to select **FM Radio** menu, then short press ▶|| to enter FM radio interface.

Manual Scan: press MENU to show options, press ◀/▶ to select **Manual** then press ▶|| button. Short press ◀ or ▶ to select frequency manually. Long press ◀ or ▶ player will auto scan and stop till it find channel.

Auto Scan: press MENU to show options, press ◀/▶ to select **Auto** then press ▶|| button. Then the player will scan channels and set the found channels to Preset one by one. After auto scan, it'll get to the first preset channel. Press ◀ or ▶ to get to preset channels one by one.

Save Channel: press MENU to show options, short press ◀/▶ to select **Memory** then press ▶|| button. Then press ◀/▶ to select position to save. Press ▶|| will pop a warning, select **Yes** and press ▶|| to confirm saving channel, or select **No** and press ▶|| to cancel saving channel.


Preset: press MENU to show options, short press ◀/▶ to select **Preset** then press ▶|| button. Press ◀/▶ to get to preset channel one by one.

Delete Channel: press MENU to show options, short press ◀/▶ to select **Delete** then press ▶|| button. Then press ◀/▶ to select to be deleted channel. Press ▶|| will pop up a warning, select **Yes** and press ▶|| to confirm deleting channel, or select **No** and press ▶|| to cancel deleting channel.

Volume: press + or - to adjust volume up or down.

Remark: Earphone should connect to player as an antenna. Otherwise the player can not receive channels.

3.4 Photo



In Main interface, short press ◀/▶ or +/- to select **Photo** menu, then short press ▶|| button to enter picture list. Press ◀/▶ to select picture file, press ▶|| button to view the picture.

Last/next: short press ◀ or ▶ to display last or next picture.

Auto Browse: short press ▶|| an arrow symbol shows on corner of display, the play will display pictures one by one automatically. (Auto Browse gap time setting reference to point 3.8.5)

Photo file list: in photo display interface, press MENU button to get to folder/file list. Press ◀/▶ to select photo file, press ▶|| button to display it.

3.5 Record



In Main interface, short press ◀/▶ or +/- to select **Record** menu, then short press ▶|| button to enter recording interface.

Record/Pause: short press ▶|| to record or pause.

Stop: long press MENU to save file and get to main interface, or long press ▶|| button to save file and turn off the player. File of recorded voice are saved in folder of VOICE.

3.6 Text




In Main interface, short press ◀/▶ or +/- to select **Text** menu, then short press ▶|| button to enter E-book file list. Press ◀/▶ to select E-book file, press ▶|| button to view the text.

Manual Browse: short press ◀/▶ or +/- to browse up or down page by page.

Auto Browse: short press ▶|| to browse page by page automatically. (Auto Browse gap time setting reference to point 3.8.3).

Text file list: in text browse interface, press MENU button to get to folder/file list. Press ◀/▶ to select text file, press ▶|| button to browse it.

3.7 Navigation




In Main interface, short press ◀/▶ or +/- to select **Navigation** menu, then short press ▶|| button to list folders/files in memory.

Play/Open file: press ◀/▶ to select file/folder, press ▶|| to play or open it. If the file is not supported by this player, it can not play or open.

Delete file: in file list, press ◀/▶ to select file then press volume - button, there will be a warning, select **Yes** to delete file, or select **No** to cancel deleting.

3.8 Settings



In Main interface, short press ◀/▶ or +/- to select **Settings** menu, then short press ▶|| button to enter setting options. (In submenu, press MENU to get to upper menu.)

3.8.1 Music:

- **Repeat mode**
Once: play one music one time.
Repeat one: repeat current music again and again.
Folder once: play all music in current folder one time.
Folder repeat: repeat all music in current folder.
All once: play all the music in memory one time.
All repeat: repeat all the music in memory.
Intro: play the first 10 seconds of each music.
- **Play mode**
Order: play music in order.
Shuffle: play music in random.
- **EQ Select**
Normal, MS PlayFX, Rock, Pop, Classic, Bass, Jazz, User EQ
- **MS PlayFX Set**
3D HeadPhone, Pure Bass
- **User EQ Set**
Set EQ by user. Press ◀/▶ to select, press +/- to adjust the frequency, press MENU confirm and get back.

3.8.2 Record:

- **Record Quality**
Set high or normal record quality.
- **Record Volume**
Set record volume level.

3.8.3 Text:

- **Auto play SW:**
Turn on/off for text auto page.
- **Auto play time:**
Set gap time for text auto page

3.8.4 FM Radio:

- **Stereo SW**
Set FM stereo on or off.
- **FM Region**
Set FM receiving region. Four options: China, Europe, Japan, USA.

3.8.5 Photo:

- **Auto play SW:**
Turn on/off for photo auto scroll.
- **Auto play time:**
Set gap time for photo auto scroll.

3.8.6 Display:

- **Backlight Time**
Set the time if no operation on play, the backlight will turn off.
- **Lum/Brightness**
Set the display brightness level.
- **Backlight Mode**
If set to Normal, the backlight will be semi dark; if set to Power Save, the backlight will be all dark when backlight time is due.

3.8.7 Power Off Time:

Set auto power off time.

3.8.8 Language:

Set player menu language.

3.8.9 System:

- **About**
View the player information of firmware version, date and memory status.
- **Upgrade**
Upgrade firmware setting. (Reference to point 4)
- **Default Set**
Set the system to original.

3.8.10 Exit:


Exit settings.

4. Firmware upgrade

If the player doesn't work or works sub normally, find the firmware upgrade tool and firmware in gift CD to upgrade the player. Processes as bellow:


Note before updating: a. Don't upgrade firmware if playing properly. b. Backup files to other storage before upgrade.

- A. Find the software file RKnanoTool.exe from folder of Upgrade Tool in gift CD. Click it to show below dialog box:



- B. Set the player to Settings>System>Upgrade, click it show warning of Firmware upgrade; select Yes and then connect the player to PC using USB cable. (In case if player can't turn on, push power button to off then hold MENU button and connect player to PC using USB cable at the same time, till PC find the player storage.). If connect successful, the dialog box will show "UsbBoot download successfully!" and show flash information, then do as below point c. If connection failed, the dialog box will show "USB device not found!", then connect again.
- C. After connecting successfully, do as below

1. Select firmware. (firmware file is in gift CD, named with extension .BIN).





- D. Disconnect the player from PC, start the player again. The player will work properly.

5. Video Convert

The player support video of AVI format in resolution of 128x128. Please use the software in gift CD to convert the video. The AVIConverter supports multi kind of video formats (AVI, RM, RMVB, MPG, MPG4, ASF, DAT, WMV, etc) convert to AVI format.

5.1 AVI Converter Tool Setup

Click software Nano_Video_convert.exe in gift CD; then follow the steps to setup the AVI Converter tool to PC.



5.2 Convert Video to AVI format

From PC>Program to run AVICConverter as below picture and steps for converting:

The screenshot shows the AVICConverter application window. It has a main window with a title bar and a menu bar. Inside, there's a 'Conversion Settings' dialog box. The dialog box has fields for 'Resolution' (set to 220x178), 'Source File' (set to F:\others\movie.avi), 'Target File Path' (set to G:\), 'Target File Name' (set to movie.avi), 'Setting' (Quality: High, Aspect Ratio: Full), and 'Begin from' and 'Time Duration' fields. There are 'Save' and 'Close' buttons at the bottom of the dialog. The main window has buttons for 'Add', 'Del', 'Convert Now', 'Stop', and 'Close'. Numbered callouts point to these elements: 1. Select Resolution: 128x128 (points to the Resolution field), 2. Select original input vido (points to the Source File field), 3. Select saving Location (points to the Target File Path field), 4. Input target file name (points to the Target File Name field), 5. Select quality, ratio and segment. (points to the Setting field), 6. Click close (points to the Close button in the dialog), 7. Click Convert (points to the Convert Now button), 8. Click save (points to the Save button in the dialog), 9. Click Add (points to the Add button in the main window).

1. Select Resolution: 128x128
2. Select original input vido
3. Select saving Location
4. Input target file name
5. Select quality, ratio and segment.
6. Click close
7. Click Convert
8. Click save
9. Click Add

After converting, copy the converted video file to the player, then enjoy it through player.

6. Accessories

Earphone 1 piece; USB cable 1 piece; drive CD 1 piece; user manual 1 piece.

Specifications

Items	SFP 5960
Dimensions	43x43x12mm (W*H*D)
TFT colored display	1.5inch TFT; 65K real color display, Diagram (128 x 128)
Language support	Multiple languages (EN, CZ, SK, HU, PL)
Data transmission speed	High speed USB2.0 Read: 4Mbps, Write: 1Mbps
Supportable file format	Music: MP3: 8K bps – 320K bps WMA: 32K bps – 320K bps WAV; 64kbps / 256kbps Picture: JPEG
Supportable video format	.AVI (All formats should be converted to .AVI format by afforded firmware)
Text	For letters with diacritics use UNICODE
S/N	85dB
Frequency response	20Hz-- 20KHz
Max. output power	10mW + 10mW
Flash memory	4GB
Power supply	3.7V li-polymer battery
Usable time of battery	Video play: 6 hours MP3 play: 16 hours (power save mode)
Working temperature	5°C to 40°C
Supporting operating system	WIN2K/XP, Mac OS 10.4.6
Weight	About 21g
Accessories	User's Manual, earphone, USB cable, installation CD disk

INSTRUCTIONS AND INFORMATION REGARDING THE DISPOSAL OF USED PACKAGING MATERIALS

Dispose of packaging material at a public waste disposal site.

DISPOSAL OF USED ELECTRICAL AND ELECTRONIC APPLIANCES



The meaning of the symbol on the product, its accessory or packaging indicates that this product shall not be treated as household waste. Please, dispose of this product at your applicable collection point for the recycling of electrical & electronic equipment waste. Alternatively in some states of the European Union or other European states you may return your products to your local retailer when buying an equivalent new product. The correct disposal of this product will help save valuable natural resources and help in preventing the potential negative impact on the environment and human health, which could be caused as a result of improper liquidation of waste. Please ask your local authorities or the nearest waste collection centre for further details. The improper disposal of this type of waste may fall subject to national regulations for fines.

For business entities in the European Union

If you wish to dispose of an electrical or electronic device, request the necessary information from your seller or supplier.

Disposal in other countries outside the European Union

If you wish to dispose of this product, request the necessary information about the correct disposal method from local government departments or from your seller.



This product meets all the basic EU regulation requirements that relate to it.

Changes to the text, design and technical specifications may occur without prior notice and we reserve the right to make these changes.

